

# Single with Deck & Extension

## Double & Deck




## Double with Deck & Extension

## Triple & Deck



Instructions for assembly, maintenance and safe use.


We constantly strive to improve our assembly instructions. To see the most current version of this instruction for assembly, maintenance and safe use. Please visit the product page at [tptoys.com](http://tptoys.com)



### **WARNING!**

THIS PRODUCT CONTAINS SMALL PARTS AND IS NOT SUITABLE FOR CHILDREN UNDER 36 MONTHS. CONTAINS SMALL PARTS. CHOKING HAZARD. ONLY FOR DOMESTIC USE. FOR OUTDOOR USE. TOY MUST BE ASSEMBLED BY AN ADULT BEFORE USE. ADULT SUPERVISION IS REQUIRED. CHILDREN MUST NOT USE THE EQUIPMENT UNTIL PROPERLY INSTALLED.

REMOVE ALL PACKAGING BEFORE GIVING TO YOUR CHILDREN. PLEASE RETAIN INSTRUCTIONS AS IT CONTAINS IMPORTANT SAFETY INFORMATION. THIS PRODUCT IS INTENDED FOR USE BY CHILDREN FROM AGES 3+ YEARS. ANCHORS THAT ARE SUPPLIED WITH THIS PRODUCT MUST BE FITTED BEFORE USE. MAXIMUM COMBINED USER WEIGHT FOR SWING FRAMES 200KGS



**Robovision Ltd t/a TP Toys**  
Unit 11, Enterprise Way, Flitwick, Bedfordshire, MK45 5BX England  
[www.tptoys.com](http://www.tptoys.com)


## Important advice for assembly, maintenance and safe use.

Please retain this information for future reference.

1. Toys must be assembled by an adult before use exactly in accordance with the instructions.
2. Check all parts are present before you start to assemble the product.
3. Place small parts on a tray or similar, to ensure they are not lost.
4. If any parts are missing do not use the product until the replacement parts are fitted.
5. Remove all packaging before giving to your children or allowing them to play with this product.
6. Ensure your product is sited on level ground. Failure to do this may put additional stress on connections and joints and in time could cause them to fail.
7. Ensure your product is located on a soft impact surface like grass. Never locate your product on hard surfaces like concrete or asphalt.
8. Children must not use this product until properly installed.
9. Adult supervision is required at all times to ensure children play safely. Ensure children's clothing is appropriate for the play activity.
10. Equipment should be checked by an adult at the beginning of each season and at regular intervals during the usage season to ensure it is safe.
11. Pay special attention to all connections and fastenings. Please check regularly all nuts and bolts for tightness and tighten as required.
12. Parts may need to be replaced if they show signs of wear and tear. Replace any defective parts in accordance with these instructions.
13. Any changes to this toy, e.g. changing or adding an accessory, must be done in accordance with our instructions. Failure to do this will render your guarantee null and void and may make your product unsafe.
14. The age recommendation for this product is clearly stated on the packaging and these instructions. Please adhere to it at all times.
15. When you dispose of this equipment please do so responsibly.

## Safe play free space area.


The safe play area refers to the zone extending 200cm around the toys on all sides and 250cm above the toy. The safe play area must be free from all obstacles.




TP821  
TP824  
TP826  
TP827

TP885  
TP886  
TP887

## Dimensions





## Understanding the TP roundwood range.

**When you experience cracks and splits in one of our roundwood timber play frames, it is not a 'defective' product, nor is its inherent strength or structural integrity impaired, it is simply exhibiting its normal state and characteristics. Each piece of timber is unique, bearing its own knots, cracks and variations in colour. These characteristics should be fully expected to be present at the time of delivery and continue to develop during the products lifecycle.**

Timber is a natural organic substance. And, as it is organic, it is greatly influenced by its surroundings. It moves, swells, and shrinks according to seasonal changes in relative humidity of the air.

TP Roundwood frames are constructed from timbers that come from younger smaller trees and are complete tree poles, stripped of any bark and other rough materials but subject to no further processing.

When a full round timber dries, the exterior surface (sapwood) shrinks faster than the inner (heartwood) heart of the timber. Consequently, stresses occur in different directions during drying. This means that the full round timber tends to develop a V-shaped check towards the centre.

Sometimes these cracks can open alarmingly in length and width, but this is entirely normal and once the inner core has dried the crack will close (not disappear). Likewise, as the moisture in the air increases so will the free water absorbed by capillary action in the wood and once again the cracks will close.


Both laboratory and field tests prove that the natural cracking and splitting does not materially affect the strength of the timber. Our frames are also designed and dimensioned to ensure these natural characteristics do not have an impact upon the structural integrity.

Our roundwood timber is pressure treated with an environmentally friendly preservative. This is a process that penetrates to the core of the wood, helps withstand the elements and wards off termites, microorganisms and fungal decay. After the treatment process it is normal for a green flecking to become visible on the surface of the wood.

Performance guarantees do not rely on a periodic application of preservative, although you may wish to do so for aesthetic reasons and to further extend the life of the product.

Because of the natural characteristics of such timber products, it is vital that parents check their play frame regularly to identify any splintering or lifting of the surface layers of the wood or any exposure of rough wood due to changes in cracks and splits. Affected areas must be rubbed down using coarse sandpaper to restore a smooth, safe surface.

There is no necessity to replace timber parts that exhibit cracks and splits. However, should your frame display a significant crack in very close proximity to a fixing point then please email a photograph that clearly illustrates the area of concern to [directsales@tp toys.com](mailto:directsales@tp toys.com) Our Quality Team will analyse the information provided and confirm if remedial action is required.



## Tools - You will need:



Mallet



Tape Measure



Step Ladder



Spirit Level

3mm & 5mm  
Drill Bits

Combi Drill



Screwdriver

Spanner  
10 & 13mmSockets  
10 & 13mm

Wrench

Pozi #2  
Pozi #3Also  
Required:

Not Supplied




Shovel

## DP - Deck Pack

821 / 824 / 826 / 827 / 885 / 886 / 887

## Contents please check:

MW0225 612mm **x3**MW0223 700mm **x14**MW0228 795mm **x1**MW0224 850mm **x4**MW0218 1400mm **x2**MW0219 1210mm **x2**MW0220 1015mm **x2**MW0221 825mm **x2**MW0226 1600mm **x2**DPL - Deck Pack Legs **x2**

821 / 824 / 826 / 827 / 885 / 886 / 887

MW0122 2668mm **x4**


## LP - Leg Pack

821 / 824 / 826 / 827 / 885 / 886 / 887

MW0200 2700mm **x2**MW0202 900mm **x1**

## DTB - Double Top Bar

821 / 824 / 826 / 885 / 887

MW0203 2250mm **x1**


## TTB - Triple Top Bar

827 / 886


MW0201 3000mm **x1**




Please note: There may be some fixings left over after the assembly build.




4.5 x 40mm FA4517  
**x64**




5 x 60mm FA9768  
**x2**




5 x 80mm FA4521  
**x16**



5 x 100mm FA9761  
**x10**



40mm FA8380  
**x8**



70mm FA8439  
**x20**



PM1968  
**x1**



4 x 16mm  
FA4527  
**x2**



PM1007  
**x1**




M8 x25mm  
FA8440  
**x20**




PM8387  
**x8**




4 x 16mm  
FA4527  
**x16**




FB6039 (Blue)  
FB6052 (Silver)  
**x2**



FB6083 (Blue)  
FB6051 (Silver)  
**x1**



PR9740  
**x2**



PR9741  
**x2**




PR5069  
**x4**




PR9598 (Blue)  
PR7757 (Silver)

**TP821 x4**  
**TP824 x3**  
**TP826 x4**  
**TP827 x5**  
**TP885 x2**  
**TP886 x3**  
**TP887 x2**




40mm FA8380  
**x5**

**TP960**




**TP960**  
**x1**

**TP995**




**TP995**  
**x1**

2



FB6052  
x2

MW0228 795mm x1




70mm FA8439  
x4




M8 x25mm  
FA8440  
x4

1



2






6

Deck with Single, Double, Triple and Extension


3

MW0122 2668mm x4




7


Deck with Single, Double, Triple and Extension



5









6



9

Deck with Single, Double, Triple and Extension


7



10

Deck with Single, Double, Triple and Extension

8







11

Deck with Single, Double, Triple and Extension



MW0226 1600mm **x2**

MW0225 612mm **x3**







10






1



13

Deck with Single, Double, Triple and Extension


11



14

Deck with Single, Double, Triple and Extension




12



70mm FA8439  
x4



M8 x25mm  
FA8440  
x4



15







Deck with Single, Double, Triple and Extension

13

MW0223 700mm x14



4.5 x 40mm FA4517  
x28



16

Deck with Single, Double, Triple and Extension



15

MW0218 1400mm **x2**





MW0220 1015mm **x2**



MW0219 1210mm **x2**



MW0221 825mm **x2**




18

Deck with Single, Double, Triple and Extension

16

4 x 16mm  
FA4527  
x2

PM8387  
x8



19

Deck with Single, Double, Triple and Extension

# 821 / 824 / 826 / 827 / 885 / 886 / 887 - Swing Arm Assembly

17

MW0203 2250mm x1




MW0201 3000mm x1



PR9598 (Blue)  
PR7757 (Silver)

TP821 x4  
TP824 x3  
TP826 x4  
TP827 x5  
TP885 x2  
TP886 x3  
TP887 x2



FB6083 (Blue)  
FB6051 (Silver)  
x1

**TP821 & TP826**

MW0203  
Double Top Bar

**TP824**

MW0203  
Double Top Bar

**TP885 & TP887**

MW0203  
Double Top Bar


**TP827**

MW0201  
Triple Top Bar

**TP886**



MW0201  
Triple Top Bar



**TP821 / 826 / 885 / 887 - no extension****ASSEMBLY TIP**

Generic view of Top Bar with Collars. Actual numbers of collars required will depend on Swing seats to be attached later.


MW2250

**TP824 / 827 / 886 - with extension**

MW0201

**Swing Frame Configuration - Using Duo Ride Brackets****IMPORTANT  
ASSEMBLY TIP**

When attaching a swing accessory that requires 2 Duo Ride Brackets (TP784 or PR5070), fixing locations for these brackets will be the same as the Swing seat positions using collars.




# Single with Deck & Extension


Locate your swing seats correctly:




## With 1 single swing seat and 1 single roped accessory



## With 1 nest swing (85cm dia) and 1 single roped accessory



## With 1 glide ride and 1 single roped accessory




## Double & Deck


Locate your swing seats correctly:




### With 2 single swing seats




### With single swing seat and single roped accessory




### With 1 glide ride and 1 single swing seat



### With 1 glide ride and 1 single roped accessory




### With 1 nest swing (120cm dia)




# Double with Deck & Extension

Locate your swing seats correctly:




40mm  
FA8380


## With 1 nest swing (120cm dia) and 1 single roped accessory






## With 2 single swing seats and 1 single roped accessory




## With 1 glide ride and 1 single swing seat and 1 single roped accessory





**23**



MW0200 2700mm **x2**




M8 x25mm Washer  
FA8440  
**x2**

**ASSEMBLY TIP**



Generic view of Top Bar only.  
Actual Top Bar will vary  
depending on product purchased.



**24**




M8 x25mm  
FA8440  
**x2**



25

MW0202 900mm x1






70mm FA8439  
x2



M8 x25mm  
FA8440  
x2

**ASSEMBLY TIP**








Generic view of Top Bar only.  
Actual Top Bar will vary  
depending on product purchased.



**ASSEMBLY TIP**

Make sure that the fixing points  
are centred on the legs.

26







27



PM1968  
x1

4 x 16mm  
FA4527 x2

PM1007  
x1



28



29








Deck with Single, Double, Triple and Extension

29

70mm FA8439  
x4


PR5069  
x4

M8 x25mm  
FA8440  
x4




30

Deck with Single, Double, Triple and Extension



Please refer to product instruction manuals supplied with swing accessories for assembly.

### IMPORTANT - Swing Accessories - Height adjustment





## Thank you

Thank you for purchasing this product.

Please register your new product on line at [tp toys.com](http://tp toys.com)

**[www.tptoys.com/customer/productregistration](http://www.tptoys.com/customer/productregistration)**

Find out about the guarantee for this product,

visit **[www.tptoys.com/customer/pages/guaranteeinformation](http://www.tptoys.com/customer/pages/guaranteeinformation)**

For customer services and help with your product,

visit **[www.tptoys.com/customer/help](http://www.tptoys.com/customer/help)**

**Your TP Guarantee Number/Product Batch No is**