


TRAMPOLINE NEW TENT



Manual depicts typical installation – your model may differ from illustrations

READ THIS FIRST!!!

Thank you for purchasing our product

IN CASE OF MISSING OR BROKEN PARTS, PLEASE CONTACT PLACE OF PURCHASE FOR ASSISTANCE.

PARTS LIST

1. PACKAGE CONTENTS

Please select your trampoline Tent

A Model: PlayRoofForRound Trampoline with safety net 13'~15' and Octagon Trampoline with safety 12'x13'~14'x15'

SEQ.	DESCRIPTION	For 4 leg trampoline	For 5 leg trampoline
1	Tube #1	8	10
2	Tube #2	8	10
3	Connector	4	5
4	New Tent	1	1
6	Screw M6x25mm	9	10
7	Screw M6x30mm	/	1
9	Metal plate	16	20
U1	Safety Nut	9	11
X1	Nylon Washer	9	11

B Model: PlayRoofForRound Trampoline with safety net 6'~12' and Octagon Trampoline with safety 7'x8'~11'x12'

SEQ.	DESCRIPTION	For 3 leg trampoline	For 4 leg trampoline
(1)	Pole	12	16
3	Connector	3	4
(4)	New Tent	1	1
5	Screw M6x20mm	1	/
6	Screw M6x25mm	/	1
U1	Safety Nut	1	1
X1	Nylon Washer	1	1

2. DIAGRAMS OF PARTS

